



1. Goto 192.168.1.1
2. Type in Username : admin Password : zoomadsl
3. VPI = 0 VCI = 35



4. username : username@gtconline.com and the password provided.
5. Click on Save / Apply
6. Click on Wireless → Basic



7. Click on Save / Apply
8. Click on Security. Change Network Security to WPA2. For the WPA/WPA2 Passphrase please type the MAC Address located on the bottom of the router.

